Key sequence	Mode	Description
g g R/S	RUN	Enter Stopwatch mode
f R/S	RUN	Enter Hexadecimal entry mode
f STO 0 - 9	RUN	Store register set in Storage Memory 0 to 9
f RCL 0 - 9	RUN	Load register set from Storage Memory 0 to 9
f RCL . 0 0	RUN	Recall constant 0-39 from Constant Collection
f STO . 0 0	RUN	Store constant 0-39 to Constant Collection
f ENTER	RUN	Show mantissa
g g RCL	RUN	Show registers 0 to 9
g g SST	PRGM	Show program steps
g g SST	RUN	Single Step Debug
GTO . 9 8	PRGM	Goto program step 00 to 98
f g	PRGM	Switch to RUN mode
g f	RUN	Switch to PRGM mode
f RCL . 0 0	PRGM	Load program 00 to 29 from Program Library
f STO . 0 0	PRGM	Store program 00 to 29 to Program Library
g g GTO 0 - 9	RUN/ PRGM	Enter Function 0-9 (see function summary)

Print keys

Key	Mode	Description
g ENTER	RUN	Paper Advance
f ENTER	RUN	Print X
g g SST	PRGM	Print Program
g g GTO 0 8	RUN/ PRGM	Toggle “Trace mode” flag

Repeat keys

Key	Description
R↓	Show stack
x≷y	Show XY registers
SST	Show program steps forward in PRGM mode

PANAMATIK © 2015

Function	Description
g g GTO	Enter Function Menu (g ENTER↑ Rev 1.03)
.	Show firmware revision and serial number
0	Toggle flags
1	Show calculator logo
2	Show ROM code
3	Show ROM checksum
4	Show program number and checksum
5	Show available Memory
6	Show operating time
7	Show Flash write cycles
8	LED Test
9	Enter welcome message

Power up keys

Key	Description
.	Show firmware revision and serial number
0 - 9	Toggle Flags 0 to 9
CLx	Toggle between Original mode and Standard or Extended mode
EEX	Toggle between External ROM and Internal ROM firmware
STO	Flash internal ROM from external ROM when in RUN mode

Stopwatch keys

Key	Description
g g R/S	Enter and leave stopwatch mode
R/S	Start and stop stopwatch timer A or B
CHS	Start and stop stopwatch timers A and B simultaneously
CLx	Reset stopwatch timer A or B
x≷y	Toggle between stopwatch timer A and B
ENTER↑	Game watch toggle between player A player B
EEX	Start and stop calibration
STO 0 - 7	Store Lap Times 0 - 7, Recall with RCL 0 - 7